



Wire feed unit

Taurus Basic S drive 4L WE Taurus Basic S drive 4 WE

Observe additional system documents!

099-005200-EW501

14.06.2011

Register now!
For your benefit
Jetzt Registrieren
und Profitieren!

www.ewm-group.com

3 Years
5 Years
transformer
and rectifier
ewm-warranty*
24 hours / 7 days

* Details for ewm-warranty
www.ewm-group.com

General instructions

CAUTION



Read the operating instructions!

The operating instructions provide an introduction to the safe use of the products.

- Read the operating instructions for all system components!
- Observe accident prevention regulations!
- Observe all local regulations!
- Confirm with a signature where appropriate.

NOTE



In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.

A list of authorised sales partners can be found at www.ewm-group.com.

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

1 Contents

1	Contents.....	3
2	Safety instructions.....	6
2.1	Notes on the use of these operating instructions	6
2.2	Explanation of icons.....	7
2.3	General	8
2.4	Transport and installation	12
2.5	Ambient conditions.....	13
2.5.1	In operation.....	13
2.5.2	Transport and storage	13
3	Intended use	14
3.1	Applications.....	14
3.1.1	MIG/MAG standard welding	14
3.1.2	MIG/MAG cored wire welding.....	14
3.1.3	MMA welding	14
3.1.4	Air arc gouging	14
3.2	Use and operation solely with the following machines	15
3.3	Documents which also apply	15
3.3.1	Warranty	15
3.3.2	Declaration of Conformity.....	15
3.3.3	Welding in environments with increased electrical hazards.....	15
3.3.4	Service documents (spare parts and circuit diagrams).....	15
4	Machine description – quick overview	16
4.1	Taurus Basic S drive 4L WE	16
4.1.1	Front view	16
4.1.2	Rear view.....	17
4.2	Taurus Basic S drive 4 WE	18
4.2.1	Front view	18
4.2.2	Inside view.....	19
4.3	Machine control – Operating elements	20
5	Design and function.....	22
5.1	General	22
5.2	Installation.....	23
5.2.1	Setting up on uneven ground	24
5.3	Welding torch cooling system	25
5.3.1	General.....	25
5.3.2	List of coolants.....	25
5.4	Intermediate hose package connection	26
5.4.1	Taurus Basic S drive 4L WE	26
5.4.2	Taurus Basic S drive 4 WE	27
5.5	Shielding gas supply	28
5.5.1	Gas test	28
5.5.2	“Rinse tube package” function.....	28
5.5.3	Setting the shielding gas quantity.....	28
5.6	MIG/MAG welding.....	29
5.6.1	Welding torch connection	29
5.6.1.1	Taurus Basic S drive 4L WE	30
5.6.1.2	Taurus Basic S drive 4 WE	31
5.6.2	Inserting the wire spool	32
5.6.3	Changing the wire feed rollers.....	32
5.6.4	Inching the wire electrode	33
5.6.5	Spool brake setting.....	34

5.6.6	Welding task selection	35
5.6.6.1	Basic welding parameters	35
5.6.6.2	Operating mode.....	35
5.6.6.3	Setting the operating point (welding output).....	35
5.6.6.4	Choke effect / dynamics	35
5.6.6.5	Accessory components for operating point setting	36
5.6.7	MIG/MAG welding data display	36
5.6.8	MIG/MAG functional sequences / operating modes	37
5.6.8.1	Explanation of signs and functions.....	37
5.6.9	Standard MIG/MAG torch	40
5.6.10	MIG/MAG special-torches.....	40
5.6.11	Remote control	40
5.7	MMA welding.....	41
5.7.1	Welding task selection	41
5.7.2	Welding current setting.....	41
5.7.3	Arcforce.....	41
5.7.4	Hotstart	41
5.7.5	Antistick.....	42
5.8	Interfaces	42
6	Maintenance, care and disposal	43
6.1	General.....	43
6.2	Maintenance work, intervals.....	43
6.2.1	Daily maintenance tasks.....	43
6.2.2	Monthly maintenance tasks	43
6.2.3	Annual test (inspection and testing during operation)	43
6.3	Maintenance work	44
6.4	Disposing of equipment.....	44
6.4.1	Manufacturer's declaration to the end user	44
6.5	Meeting the requirements of RoHS.....	44
7	Rectifying faults.....	45
7.1	Customer checklist.....	45
7.2	Error messages (power source).....	46
8	Technical data.....	47
8.1	Taurus Basic S drive 4L WE	47
8.2	Taurus Basic S drive 4 WE	47
9	Accessories	48
9.1	General accessories	48
9.2	Remote control / connection cable.....	48
9.3	Options.....	48
9.3.1	Taurus Basic S drive 4L WE.....	48
9.3.2	Taurus Basic S drive 4 WE.....	48
10	Replaceable parts.....	49
10.1	Wire feed rollers	49
10.1.1	Wire feed rollers for steel wire	49
10.1.2	Wire feed rollers for aluminium wire	49
10.1.3	Wire feed rollers for cored wire.....	49
10.1.4	Conversion sets	49
11	Appendix A.....	51
11.1	Overview of EWM branches.....	51

2 Safety instructions

2.1 Notes on the use of these operating instructions



DANGER

Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.

- Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.



WARNING

Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.



CAUTION

Working or operating procedures which must be closely observed to prevent possible minor personal injury.

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- The risk is explained using a symbol on the edge of the page.

CAUTION

Working and operating procedures which must be followed precisely to avoid damaging or destroying the product.

- The safety information includes the "CAUTION" keyword in its heading without a general warning symbol.
- The hazard is explained using a symbol at the edge of the page.

NOTE














Special technical points which users must observe.

- Notes include the "NOTE" keyword in the heading without a general warning symbol.

Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

- Insert the welding current lead socket into the relevant socket and lock.

2.2 Explanation of icons

Symbol	Description
	Press
	Do not press
	Turn
	Switch
	Switch off machine
	Switch on machine
	ENTER (enter the menu)
	NAVIGATION (Navigating in the menu)
	EXIT (Exit the menu)
	Time display (example: wait 4s/press)
	Interruption in the menu display (other setting options possible)
	Tool not required/do not use
	Tool required/use

2.3 General



DANGER



Electromagnetic fields!

The power source may cause electrical or electromagnetic fields to be produced which could affect the correct functioning of electronic equipment such as IT or CNC devices, telecommunication lines, power cables, signal lines and pacemakers.

- Observe the maintenance instructions! (see Maintenance and Testing chapter)
- Unwind welding leads completely!
- Shield devices or equipment sensitive to radiation accordingly!
- The correct functioning of pacemakers may be affected (obtain advice from a doctor if necessary).



Do not carry out any unauthorised repairs or modifications!

To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!

The warranty becomes null and void in the event of unauthorised interference.

- Appoint only skilled persons for repair work (trained service personnel)!



Electric shock!

Welding machines use high voltages which can result in potentially fatal electric shocks and burns on contact. Even low voltages can cause you to get a shock and lead to accidents.

- Do not touch any live parts in or on the machine!
- Connection cables and leads must be free of faults!
- Switching off alone is not sufficient!
- Place welding torch and stick electrode holder on an insulated surface!
- The unit should only be opened by specialist staff after the mains plug has been unplugged!
- Only wear dry protective clothing!
- Wait for 4 minutes until the capacitors have discharged!



WARNING



Validity of this document!

This document is only valid in combination with the operating instructions for the power source being used (welding machine)!

- Read the operating instructions, in particular the safety instructions for the power source (welding machine)!



Risk of accidents if these safety instructions are not observed!

Non-observance of these safety instructions is potentially fatal!

- Carefully read the safety information in this manual!
- Observe the accident prevention regulations in your country.
- Inform persons in the working area that they must observe the regulations!

**WARNING****Risk of injury due to radiation or heat!**

Arc radiation results in injury to skin and eyes.

Contact with hot workpieces and sparks results in burns.

- Use welding shield or welding helmet with the appropriate safety level (depending on the application)!
- Wear dry protective clothing (e.g. welding shield, gloves, etc.) according to the relevant regulations in the country in question!
- Protect persons not involved in the work against arc beams and the risk of glare using safety curtains!

**Explosion risk!**

Apparently harmless substances in closed containers may generate excessive pressure when heated.

- Move containers with inflammable or explosive liquids away from the working area!
- Never heat explosive liquids, dusts or gases by welding or cutting!

**Smoke and gases!**

Smoke and gases can lead to breathing difficulties and poisoning. In addition, solvent vapour (chlorinated hydrocarbon) may be converted into poisonous phosgene due to the ultraviolet radiation of the arc!

- Ensure that there is sufficient fresh air!
- Keep solvent vapour away from the arc beam field!
- Wear suitable breathing apparatus if appropriate!

**Fire hazard!**

Flames may arise as a result of the high temperatures, stray sparks, glowing-hot parts and hot slag produced during the welding process.

Stray welding currents can also result in flames forming!

- Check for fire hazards in the working area!
- Do not carry any easily flammable objects such as matches or lighters.
- Keep appropriate fire extinguishing equipment to hand in the working area!
- Thoroughly remove any residue of flammable substances from the workpiece before starting welding.
- Only continue work on welded workpieces once they have cooled down.
Do not allow to come into contact with flammable material!
- Connect welding leads correctly!

**CAUTION****Noise exposure!**

Noise exceeding 70 dBA can cause permanent hearing damage!

- Wear suitable ear protection!
- Persons located within the working area must wear suitable ear protection!

CAUTION



Obligations of the operator!

The respective national directives and laws must be observed for operation of the machine!

- National implementation of the framework directive (89/391/EEG), as well as the associated individual directives.
- In particular, directive (89/655/EEG), on the minimum regulations for safety and health protection when staff members use equipment during work.
- The regulations regarding work safety and accident prevention for the respective country.
- Setting up and operating the machine according to IEC 60974-9.
- Check at regular intervals that users are working in a safety-conscious way.
- Regular checks of the machine according to IEC 60974-4.



Damage due to the use of non-genuine parts!

The manufacturer's warranty becomes void if non-genuine parts are used!

- Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!
- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.



Damage to the machine due to stray welding currents!

Stray welding currents can destroy protective earth conductors, damage equipment and electronic devices and cause overheating of components leading to fire.

- Make sure all welding leads are securely connected and check regularly.
- Always ensure a proper and secure electrical connection to the workpiece!
- Set up, attach or suspend all conductive power source components like casing, transport vehicle and crane frames so they are insulated!
- Do not place any other electronic devices such as drillers or angle grinders, etc., on the power source, transport vehicle or crane frames unless they are insulated!
- Always put welding torches and electrode holders on an insulated surface when they are not in use!



Mains connection

Requirements for connection to the public mains network

High-performance machines can influence the mains quality by taking current from the mains network. For some types of machines, connection restrictions or requirements relating to the maximum possible line impedance or the necessary minimum supply capacity at the interface with the public network (Point of Common Coupling, PCC) can therefore apply. In this respect, attention is also drawn to the machines' technical data. In this case, it is the responsibility of the operator, where necessary in consultation with the mains network operator, to ensure that the machine can be connected.

CAUTION**EMC Machine Classification**

In accordance with IEC 60974-10, welding machines are grouped in two electromagnetic compatibility classes (see technical data):

Class A machines are not intended for use in residential areas where the power supply comes from the low-voltage public mains network. When ensuring the electromagnetic compatibility of class A machines, difficulties can arise in these areas due to interference not only in the supply lines but also in the form of radiated interference.

Class B machines fulfil the EMC requirements in industrial as well as residential areas, including residential areas connected to the low-voltage public mains network.

Setting up and operating

When operating arc welding systems, in some cases, electro-magnetic interference can occur although all of the welding machines comply with the emission limits specified in the standard. The user is responsible for any interference caused by welding.

In order to **evaluate** any possible problems with electromagnetic compatibility in the surrounding area, the user must consider the following: (see also EN 60974-10 Appendix A)

- Mains, control, signal and telecommunication lines
- Radios and televisions
- Computers and other control systems
- Safety equipment
- The health of neighbouring persons, especially if they have a pacemaker or wear a hearing aid
- Calibration and measuring equipment
- The immunity to interference of other equipment in the surrounding area
- The time of day at which the welding work must be carried out

Recommendations for reducing interference emission

- Mains connection, e.g. additional mains filter or shielding with a metal tube
- Maintenance of the arc welding equipment
- Welding lines should be as short as possible and run closely together along the ground
- Potential equalization
- Earthing of the workpiece. In cases where it is not possible to earth the workpiece directly, it should be connected by means of suitable capacitors.
- Shielding from other equipment in the surrounding area or the entire welding system

2.4 Transport and installation



WARNING



Incorrect handling of shielding gas cylinders!

Incorrect handling of shielding gas cylinders can result in serious and even fatal injury.

- Observe the instructions from the gas manufacturer and in any relevant regulations concerning the use of compressed air!
- Place shielding gas cylinders in the holders provided for them and secure with fixing devices.
- Avoid heating the shielding gas cylinder!



Risk of accident due to improper transport of machines that may not be lifted!

Do not lift or suspend the machine! The machine can fall down and cause injuries! The handles and brackets are suitable for transport by hand only!

- The machine may not be lifted by crane or suspended!



CAUTION



Risk of tipping!

There is a risk of the machine tipping over and injuring persons or being damaged itself during movement and set up. Tilt resistance is guaranteed up to an angle of 10° (according to IEC 60974-1, -3, -10).

- Set up and transport the machine on level, solid ground.
- Secure add-on parts using suitable equipment.



Damage due to supply lines not being disconnected!

During transport, supply lines which have not been disconnected (mains supply leads, control leads, etc.) may cause hazards such as connected equipment tipping over and injuring persons!

- Disconnect supply lines!

CAUTION



Equipment damage when not operated in an upright position!

The units are designed for operation in an upright position!

Operation in non-permissible positions can cause equipment damage.

- Only transport and operate in an upright position!

2.5 Ambient conditions



CAUTION



Installation site!

The machine must not be operated in the open air and must only be set up and operated on a suitable, stable and level base!

- The operator must ensure that the ground is non-slip and level, and provide sufficient lighting for the place of work.
- Safe operation of the machine must be guaranteed at all times.

CAUTION



Equipment damage due to dirt accumulation!

Unusually high quantities of dust, acid, corrosive gases or substances may damage the equipment.

- Avoid high volumes of smoke, vapour, oil vapour and grinding dust!
- Avoid ambient air containing salt (sea air)!



Non-permissible ambient conditions!

Insufficient ventilation results in a reduction in performance and equipment damage.

- Observe the ambient conditions!
- Keep the cooling air inlet and outlet clear!
- Observe the minimum distance of 0.5 m from obstacles!

2.5.1 In operation

Temperature range of the ambient air:

- -20 °C to +40 °C

Relative air humidity:

- Up to 50% at 40 °C
- Up to 90% at 20 °C

2.5.2 Transport and storage

Storage in an enclosed space, temperature range of the ambient air:

- -25 °C to +55 °C

Relative air humidity

- Up to 90% at 20 °C

3 Intended use

This machine has been manufactured according to the latest developments in technology and current regulations and standards. It must only be operated in line with the instructions on correct usage.



WARNING



Hazards due to improper usage!

Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!

- The equipment must only be used in line with proper usage and by trained or expert staff!
- Do not modify or convert the equipment improperly!

3.1 Applications

3.1.1 MIG/MAG standard welding

Metal arc welding using a wire electrode whereby gas from an external source surrounds the arc and the molten pool to protect them from the atmosphere.

3.1.2 MIG/MAG cored wire welding

Welding with cored wire electrodes consisting of a metal casing and a powder core.

As with MIG/MAG standard welding, the arc is protected from the atmosphere by shielding gas. The gas is supplied either externally (gas shielded cored wires) or produced in the arc by means of the powder core (self-shielding cored wires).

3.1.3 MMA welding

Manual arc welding or, for short, MMA welding. It is characterised by the fact that the arc burns between a melting electrode and the molten pool. There is no external protection; any protection against the atmosphere comes from the electrode.

3.1.4 Air arc gouging

During air arc gouging, bad welding seams are heated with a carbon electrode and then removed with compressed air. Special electrode holders and carbon electrodes are required for air arc gouging.

3.2 Use and operation solely with the following machines

NOTE



A suitable power source (system component) is required in order to operate the wire feed unit!

	Taurus Basic S 351	Taurus Basic S 451	Taurus Basic S 551
Taurus Basic S drive 200C WE	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Taurus Basic S drive 300C WE	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Taurus Basic S drive 4L	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Taurus Basic S drive 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

3.3 Documents which also apply

3.3.1 Warranty

NOTE



For further information, please see the accompanying supplementary sheets "Machine and Company Data, Maintenance and Testing, Warranty"!

3.3.2 Declaration of Conformity



The designated machine conforms to EC Directives and standards in terms of its design and construction:

- EC Low Voltage Directive (2006/95/EC),
- EC EMC Directive (2004/108/EC),

This declaration shall become null and void in the event of unauthorised modifications, improperly conducted repairs, non-observance of the deadlines for the repetition test and / or non-permitted conversion work not specifically authorised by the manufacturer.

The original copy of the declaration of conformity is enclosed with the unit.

3.3.3 Welding in environments with increased electrical hazards



In compliance with IEC / DIN EN 60974, VDE 0544 the machines can be used in environments with an increased electrical hazard.

3.3.4 Service documents (spare parts and circuit diagrams)



DANGER



Do not carry out any unauthorised repairs or modifications!

To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!

The warranty becomes null and void in the event of unauthorised interference.

- Appoint only skilled persons for repair work (trained service personnel)!

Original copies of the circuit diagrams are enclosed with the unit.

Spare parts can be obtained from the relevant authorised dealer.

4 Machine description – quick overview

4.1 Taurus Basic S drive 4L WE

4.1.1 Front view








Figure 4-1

Item	Symbol	Description
1		Slide latch, lock for the protective cap
2		Label, Wire feed parts subject to wear
3		Cover for wire delivery unit and operating elements
4		Carrying handle
5		Wire spool casing
6		Wire spool retainer
7		Wire delivery unit
8		Central connection for welding torch (Euro) Integrated welding current, shielding gas and torch trigger

Item	Symbol	Description
9		Machine control See Machine control – operating elements chapter
10		19-pole connection socket (analogue) For connecting analogue accessory components (remote control, welding torch control lead, etc.)
11		Rapid-action closure coupling (blue) coolant supply
12		Rapid-action closure coupling (red) coolant return

4.1.2 Rear view









Figure 4-2

Item	Symbol	Description
1		Intermediate tube package strain relief
2		7-pole connection socket (digital) • Control lead for wire feed unit
3		Connecting nipple G$\frac{1}{4}$, shielding gas connection
4		Rapid-action closure coupling, red (coolant return)
5		Rapid-action closure coupling, blue (coolant supply)
6		Connector plug, welding current "+" Welding current connection on wire feed unit

4.2 Taurus Basic S drive 4 WE

4.2.1 Front view




Figure 4-3

Item	Symbol	Description
1		Cover for wire delivery unit and operating elements
2		Recessed grip (catch) for opening the cover
3		Slide latch, lock for the protective cap
4		Machine feet
5		Torch connection (Euro or Dinse central) Integrated with welding current and shielding gas
6		Rapid-action closure coupling (red) coolant return
7		Rapid-action closure coupling (blue) coolant supply
8		19-pole connection socket (analogue) For connecting analogue accessory components (remote control, welding torch control lead, etc.)
9		Machine control See Machine control – operating elements chapter
10		Carrying handle

4.2.2 Inside view









Figure 4-4

Item	Symbol	Description
1		Wire delivery unit
2		7-pole connection socket (digital) • Control lead for wire feed unit
3		Connecting nipple G $\frac{1}{4}$, shielding gas connection
4		Wire spool retainer
5		Rapid-action closure coupling, blue (coolant supply)
6		Connector plug, welding current "+" Welding current connection on wire feed unit
7		Rapid-action closure coupling, red (coolant return)
8		Strain relief

4.3 Machine control – Operating elements










Figure 4-5

Item	Symbol	Description
1		Button, welding process GMAW ● MIG / MAG MMA ● E-HAND MMAG ● FUGENHOBELN
2		Wire inching button See also "Inching the Wire Electrode" chapter
3		Gas test / rinse button • Gas test: For setting the shielding gas quantity • Rinse: For rinsing longer tube packages See also "Shielding Gas Supply" chapter
4		Display, left Welding current as actual value or hold value, wire-feed speed as nominal value.
5		Display, right Welding voltage
6		Rotary dial, wire speed Wire speed setting 0.5 to 24 m/min
7		Rotary dial, welding voltage Adjustment of the welding voltage from min. to max. (twin-knob operation: wire speed/welding voltage)

Item	Symbol	Description
8		Operating mode changeover switch Switching between non-latched and latched operating modes  Non-latched operation  Latched operation
9		Dynamics/choke effect button  Arc harder and narrower  Arc softer and wider

5 Design and function

NOTE



Observe documentation of other system components when connecting!

5.1 General



WARNING



Risk of injury from electric shock!

Contact with live parts, e.g. welding current sockets, is potentially fatal!

- Follow safety instructions on the opening pages of the operating instructions.
- Commissioning may only be carried out by persons who have the relevant expertise of working with arc welding machines!
- Connection and welding leads (e.g. electrode holder, welding torch, workpiece lead, interfaces) may only be connected when the machine is switched off!



CAUTION



Risk of burns on the welding current connection!

If the welding current connections are not locked, connections and leads heat up and can cause burns, if touched!

- Check the welding current connections every day and lock by turning in clockwise direction, if necessary.



Risk of injury due to moving parts!

The wire feed units are equipped with moving parts, which can trap hands, hair, clothing or tools and thus injure persons!

- Do not reach into rotating or moving parts or drive components!
- Keep casing covers closed during operation!



Risk of injury due to welding wire escaping in an unpredictable manner!

Welding wire can be conveyed at very high speeds and, if conveyed incorrectly, may escape in an uncontrolled manner and injure persons!

- Before mains connection, set up the complete wire guide system from the wire spool to the welding torch!
- Remove the counter pressure rollers from the wire feed unit if no welding torch is fitted!
- Check wire guide at regular intervals!
- Keep all casing covers closed during operation!



Risk from electrical current!

If welding is carried out alternately using different methods and if a welding torch and an electrode holder remain connected to the machine, the open-circuit/welding voltage is applied simultaneously on all cables.

- The torch and the electrode holder should therefore always be placed on an insulated surface before starting work and during breaks.

CAUTION**Damage due to incorrect connection!**

Accessory components and the power source itself can be damaged by incorrect connection!

- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.
- Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.
- Accessory components are detected automatically after the power source is switched on.

**Using protective dust caps!**

Protective dust caps protect the connection sockets and therefore the machine against dirt and damage.

- The protective dust cap must be fitted if there is no accessory component being operated on that connection.
- The cap must be replaced if faulty or if lost!

5.2 Installation

**WARNING**

Risk of accident due to improper transport of machines that may not be lifted!

Do not lift or suspend the machine! The machine can fall down and cause injuries! The handles and brackets are suitable for transport by hand only!

- The machine may not be lifted by crane or suspended!

**CAUTION****Installation site!**

The machine must not be operated in the open air and must only be set up and operated on a suitable, stable and level base!

- The operator must ensure that the ground is non-slip and level, and provide sufficient lighting for the place of work.
- Safe operation of the machine must be guaranteed at all times.

NOTE

Crane handling is optional, depending on the model, and may have to be retrofitted (See "Accessories" chapter)!

5.2.1 Setting up on uneven ground



WARNING




Risk of accidents due to improper set-up location!

The machines are designed for operation in an upright position!

In the event of incorrect setting up of the machine and adjustment of the wire feed retainer, the wire spool can fall out of the machine!

- Machines may only be assembled by trained specialist staff!
- Only assemble and operate machines in the recommended positions.
- With assembly on existing cross arms or similar constructions, the weight of the wire spool must not lay on the knurled nut of the wire feed retainer.
- Observe the information about adjustment in the chapter "Fixing the wire spool retainer".



Installing the wire feed unit on uneven ground may put strain on the knurled nut of the wire spool holder. To avoid this, make sure to properly align the wire feed unit when installing.

The unit can be installed on even ground and also so that it is tilted to the right.

If the wire feed unit is tilted forwards, the tilt angle to the right has to be greater than 5°.

Example:




Figure 5-1

5.3 Welding torch cooling system

5.3.1 General

CAUTION

**Coolant mixtures!**

Mixtures with other liquids or the use of unsuitable coolants result in material damage and renders the manufacturer's warranty void!

- Only use the coolant described in this manual (overview of coolants).
- Do not mix different coolants.
- When changing the coolant, the entire volume of liquid must be changed.

**Insufficient frost protection in the welding torch coolant!**

Depending on the ambient conditions, different liquids are used for cooling the welding torch (see overview of coolants).

Coolants with frost protection (KF 37E or KF 23E) must be checked regularly to ensure that the frost protection is adequate to prevent damage to the machine or the accessory components.

- The coolant must be checked for adequate frost protection with the TYP 1 frost protection tester (see accessories).
- Replace coolant as necessary if frost protection is inadequate!

NOTE



The disposal of coolant must be carried out according to official regulations and observing the relevant safety data sheets (German waste code number: 70104)!

- Coolant must not be disposed of together with household waste.
- Coolant must not be discharged into the sewerage system.
- Recommended cleaning agent: water, if necessary with cleaning agent added.

5.3.2 List of coolants

The following coolants may be used (for item nos., please see the Accessories chapter):

Coolant	Temperature range
KF 23E (Standard)	-10 °C to +40 °C
KF 37E	-20 °C to +10 °C
DKF 23E (for plasma machines)	0 °C to +40 °C

5.4 Intermediate hose package connection

5.4.1 Taurus Basic S drive 4L WE




Figure 5-2

Item	Symbol	Description
1		Power source
2		Intermediate tube package
3		7-pole connection socket (digital) • Control lead for wire feed unit
4		Connecting nipple G$\frac{1}{4}$, shielding gas connection
5		Rapid-action closure coupling, red (coolant return)
6		Connector plug, welding current "+" Welding current connection on wire feed unit
7		Rapid-action closure coupling, blue (coolant supply)
8		Intermediate tube package strain relief

- Insert the end of the tube package through the strain relief of the tube package and lock by turning to the right.
- Push the welding current cable socket onto the "welding current connecting plug" and lock by turning to the right.
- Connect crown nut of the shielding gas line to the G $\frac{1}{4}$ " connecting nipple.
- Insert cable plug on the control lead into the 7-pole connection socket and secure with crown nut (the plug can only be inserted into the connection socket in one position).
- Lock connecting nipples of the cooling water tubes into the corresponding rapid-action closure couplings:
Return line red to rapid-action closure coupling, red (coolant return) and supply line blue to rapid-action closure coupling, blue (coolant supply).

5.4.2 Taurus Basic S drive 4 WE









Figure 5-3

Item	Symbol	Description
1		Power source
2		Intermediate tube package
3	 digital	7-pole connection socket (digital) Connection of control lead connection to power source
4		Connecting nipple G$\frac{1}{4}$, shielding gas connection
5		Rapid-action closure coupling, blue (coolant supply)
6		Connector plug, welding current "+" Welding current connection
7		Strain relief
8		Rapid-action closure coupling, red (coolant return)

- Insert the end of the tube package through the strain relief of the tube package and lock by turning to the right.
- Push the welding current cable socket onto the "welding current connecting plug" and lock by turning to the right.
- Connect crown nut of the shielding gas line to the G $\frac{1}{4}$ " connecting nipple.
- Insert cable plug on the control lead into the 7-pole connection socket and secure with crown nut (the plug can only be inserted into the connection socket in one position).
- Lock connecting nipples of the cooling water tubes into the corresponding rapid-action closure couplings:
Return line red to rapid-action closure coupling, red (coolant return) and supply line blue to rapid-action closure coupling, blue (coolant supply).


5.5 Shielding gas supply

NOTE





A pilot static tube for a gas flow of 0-16 l/min is fitted on each wire feed unit as standard. For applications where a higher gas flow rate is required (e.g. for aluminium), a pilot static tube of 0-25 l/min (see accessories) should be installed.

5.5.1 Gas test

- Slowly open the gas cylinder valve.
- Open the pressure reducer.
- Switch on the power source at the main switch.
- Initiate gas test function on the machine control.
- Set the relevant gas quantity for the application on the pressure reducer.
- The gas test is triggered on the machine control by pressing the  button briefly.

Shielding gas flows for around 25 seconds or until the button is pressed again.

5.5.2 "Rinse tube package" function

Operating Element	Action	Result
	 5 s	Select rinse tube package. Shielding gas flows continuously until the Gas Test button is pressed again.

5.5.3 Setting the shielding gas quantity

Welding process	Recommended shielding gas quantity
MAG welding	Wire diameter x 11.5 = l/min
MIG brazing	Wire diameter x 11.5 = l/min
MIG welding (aluminium)	Wire diameter x 13.5 = l/min (100 % argon)
TIG	Gas nozzle diameter in mm corresponds to l/min gas throughput

Helium-rich gas mixtures require a higher gas volume!

The table below can be used to correct the gas volume calculated where necessary:

Shielding gas	Factor
75% Ar/25% He	1.14
50% Ar/50% He	1.35
25% Ar/75% He	1.75
100% He	3.16

NOTE



Incorrect shielding gas setting!

If the shielding gas setting is too low or too high, this can introduce air to the weld pool and may cause pores to form.

- Adjust the shielding gas quantity to suit the welding task!

5.6 MIG/MAG welding

5.6.1 Welding torch connection

CAUTION



Equipment damage due to improperly connected coolant lines!

If the coolant lines are not connected or a gas-cooled welding torch is used, the coolant circuit is interrupted and equipment damage can occur.

- Connect all coolant lines correctly!
- When using a gas-cooled welding torch, add a tube bridge to the coolant circuit (see chapter "Accessories").

NOTE



Fault with the wire guide!

On delivery, the central connector (Euro) is fitted with a capillary tube for welding torches with spiral guides. Conversion is necessary if a welding torch with a plastic core is used!

Welding torch with plastic core:

- use with guide tube!

Welding torch with spiral guide:

- use with capillary tube!

Depending on the wire electrode diameter or type, either a spiral guide or plastic core with the correct inner diameter has to be inserted in the torch!

Recommendation:

- Use a spiral guide to weld hard, unalloyed wire electrodes (steel).
- Use a plastic core to weld or braze soft, high-alloy wire electrodes or aluminium materials.

Preparation for connecting welding torches with a plastic core:

- Push forward the capillary tube on the wire feed side in the direction of the central connector and remove it there.
- Slide plastic core guide tube off the central connector.
- Carefully insert the central plug for the welding torch, with the still oversized plastic liner, into the central connector and screw together with crown nut.
- Use a suitable tool to cut off the plastic liner just before the wire feed roller, making sure not to pinch it.
- Unfasten and remove the central plug on the welding torch.
- Cleanly remove the burr from the separated end of the plastic core!

Preparation for connecting welding torches with a spiral guide:

- Check that the capillary tube is correctly positioned in relation to the central connector!

5.6.1.1 Taurus Basic S drive 4L WE










Figure 5-4

Item	Symbol	Description
1		Welding torch
2		Welding torch hose package
3		Central connection for welding torch (Euro) Integrated welding current, shielding gas and torch trigger
4		19-pole connection socket (analogue) For connecting analogue accessory components (remote control, welding torch control lead, etc.)
5		Rapid-action closure coupling (blue) coolant supply
6		Rapid-action closure coupling (red) coolant return

- Insert the central plug for the welding torch into the central connector and screw together with crown nut.
- Lock connecting nipples of the cooling water tubes into the corresponding rapid-action closure couplings:
Return line red to rapid-action closure coupling, red (coolant return) and supply line blue to rapid-action closure coupling, blue (coolant supply).

Only MIG/MAG torches with special functions (additional control lead):

- Insert the torch control lead plug into the 19-pole connection socket and lock in place.

5.6.1.2 Taurus Basic S drive 4 WE










Figure 5-5

Item	Symbol	Description
1		Welding torch
2		Welding torch hose package
3		Central connection for welding torch (Euro) Integrated welding current, shielding gas and torch trigger
4		Rapid-action closure coupling (red) coolant return
5		Rapid-action closure coupling (blue) coolant supply
6		19-pole connection socket (analogue) For connecting analogue accessory components (remote control, welding torch control lead, etc.)

- Insert the central plug for the welding torch into the central connector and screw together with crown nut.
- Lock connecting nipples of the cooling water tubes into the corresponding rapid-action closure couplings:
Return line red to rapid-action closure coupling, red (coolant return) and supply line blue to rapid-action closure coupling, blue (coolant supply).

Only MIG/MAG torches with special functions (additional control lead):

- Insert the torch control lead plug into the 19-pole connection socket and lock in place.

5.6.2 Inserting the wire spool

NOTE



Standard D300 pin reels can be used. Adapters (see accessories) are required when using standardised basket coils (DIN 8559).




Figure 5-6

Item	Symbol	Description
1		Carrier pin For fixing the wire spool
2		Knurled nut For fixing the wire spool

- Loosen knurled nut from spool holder.
- Fix welding wire reel onto the spool holder so that the carrier pin locks into the spool bore.
- Fasten wire spool using knurled nut.

5.6.3 Changing the wire feed rollers

NOTE



Unsatisfactory welding results due to faulty wire feeding!

Wire feed rollers must be suitable for the diameter of the wire and the material.

- Check the roller label to verify that the rollers are suitable for the wire diameter. Turn or change if necessary!
- use V-Nut rollers with for steel wires and other hard wires,
- use U-Nut rollers for aluminium wires and other soft, alloyed wires.

- Slide new drive rollers into place so that the diameter of the wire used is visible on the drive roller.
- Screw the drive rollers in place with knurled screws.




Figure 5-7

5.6.4 Inching the wire electrode



CAUTION



Risk of injury due to welding wire escaping from the welding torch!

The welding wire can escape from the welding torch at high speed and cause bodily injury including injuries to the face and eyes!

- Never direct the welding torch towards your own body or towards other persons!



Risk of injury due to moving parts!

The wire feed units are equipped with moving parts, which can trap hands, hair, clothing or tools and thus injure persons!

- Do not reach into rotating or moving parts or drive components!
- Keep casing covers closed during operation!

CAUTION



Extensive wear due to incorrect contact pressure!

Incorrect contact pressure will cause extensive wear of the wire feed rollers!

- With the adjusting nuts of the pressure units set the contact pressure so that the wire electrode is conveyed but will still slip through if the wire spool jams.
- Set the contact pressure of the front rollers (in wire feed direction) to a higher value!




Figure 5-8

NOTE



Depending on the design of the machine, the design of the wire feed may be the reverse of that shown!

Item	Symbol	Description
1		Pressure units
2		Clamping units
3		Knurled nut
4		Counterpressure rollers
5		Wire holding nipple
6		Guide tube
7		Drive rollers
8		"Undetachable" knurled screws
9		Wire feed nipple with wire stabiliser
10		"Wire inlet nipple" fixing screw

- Extend and lay out the torch tube package.
- Unfasten pressure units and fold out (clamping units and counter-pressure rollers will automatically flip upwards).
- Unwind welding wire carefully from the wire spool and insert through the wire inlet nipple over the drive roller grooves and the guide pipe into the capillary tube and Teflon core using guide pipe.
- Press the clamping element with the counter pressure roller back downwards and fold the wire units back up again (wire electrode should be in the groove on the drive roller).
- Set the contact pressure with the adjusting nuts of the pressure unit.
- Press the wire inching button until the wire electrode projects out of the welding torch.

NOTE



The inching speed is infinitely adjustable by simultaneously pressing the wire inching button and turning the wire speed rotary dial. The display shows the selected inching speed.

5.6.5 Spool brake setting




Figure 5-9

Item	Symbol	Description
1		Allen screw Securing the wire spool retainer and adjustment of the spool brake

- Tighten the Allen screw (8 mm) in the clockwise direction to increase the braking effect.

NOTE



Tighten the spool brake until the wire spool no longer turns when the wire feed motor stops but without it jamming during operation!

5.6.6 Welding task selection

5.6.6.1 Basic welding parameters

Operating element	Action	Result
		Welding process selection Signal light GMAW MIG / MAG on.

5.6.6.2 Operating mode

Operating element	Action	Result
		Operating mode selection The signal light indicates the selected operating mode. Non-latched operation Latched operation

The operating point is set with the wire speed and arc length rotary dials.

The operating point setting can also be specified using accessory components such as remote control, welding torch, etc.

5.6.6.3 Setting the operating point (welding output)

The M3.77 control works according to the twin-knob operation principle. To set the operating point, only the wire speed and the welding voltage need to be set according to the material and the electrode diameter.

Operating element	Action	Result
		Wire speed setting 0,5 bis 24 m/min
		Welding voltage setting 10 V bis 49,8 V

5.6.6.4 Choke effect / dynamics




Figure 5-10

Display	Setting/selection
	Dynamics setting 40: Arc harder and narrower -40: Arc softer and wider

5.6.6.5 Accessory components for operating point setting

The operating point setting can also be made with the accessory components

- R11 / RG11 remote control
- Up/Down torch with two rockers (2 U/D)

You will find an overview of accessory components in the "Accessories" chapter. See the operating instructions for the machine in question for a more detailed description of the individual machines and their functions.

5.6.7 MIG/MAG welding data display




Figure 5-11

Item	Symbol	Description
1		Signal light, AMP During welding, the left display shows the actual welding current value. After welding, the welding current hold value is displayed.
2		Signal light, WF The left display shows the nominal value for the wire feed
3		Display, left Welding current as actual value or hold value, wire-feed speed as nominal value.
4		Display, right Welding voltage
5		Signal light, coolant fault Low coolant level
6		Signal light, excess temperature Excess temperature, welding machine












5.6.8 MIG/MAG functional sequences / operating modes

NOTE



Welding parameters such as gas pre-flows wire burn-back etc. are pre-set with optimal values for numerous applications. These values can, however, be changed with the PC300.NET software as required.

5.6.8.1 Explanation of signs and functions

Symbol	Meaning
	Press torch trigger
	Release torch trigger
	Tap torch trigger (press briefly and release)
	Shielding gas flowing
I	Welding output
	Wire electrode is being conveyed
	Wire creep
	Wire burn-back
	Gas pre-flows
	Gas post-flows
	Non-latched
	Latched
t	Time
PSTART	Ignition program
PA	Main program
PEND	End program

Non-latched mode




Figure 5-12

Step 1

- Press and hold torch trigger.
- Shielding gas is expelled (gas pre-flows).
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Change over to pre-selected wire speed.

Step 2

- Release torch trigger.
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

Latched mode




Figure 5-13

Step 1

- Press and hold torch trigger
- Shielding gas is expelled (gas pre-flows)
- Wire feed motor runs at "creep speed".
- Arc ignites after the wire electrode makes contact with the workpiece; welding current flows.
- Change over to pre-selected WF speed (main program P_A).

Step 2

- Release torch trigger (no effect)

Step 3


- Press torch trigger (no effect)

Step 4

- Release torch trigger
- WF motor stops.
- Arc is extinguished after the preselected wire burn-back time expires.
- Gas post-flow time elapses.

5.6.9 Standard MIG/MAG torch

The MIG welding torch trigger is essentially used to start and stop the welding process.

Operating elements	Functions
 Torch trigger	<ul style="list-style-type: none"> Start/stop welding

5.6.10 MIG/MAG special-torches

Function specifications and more indepth information can be found in the operating manual for the relevant welding torch!

The following special torches can be used together with this welding machine:

- UP/DOWN welding torch with two rocker buttons
 - for setting the wire-feed speed and
 - for setting the welding performance.

5.6.11 Remote control

CAUTION



Damage to the machine due to improper connection!

The remote controls have been developed to be connected to welding machines or wire feed units only. Connecting them to other machines may cause damage to the machines!

- Observe the operating instructions for the welding machine or wire feed unit!
- Switch off the welding machine before connecting!

The operation of the remote control and its settings are directly dependent on the configuration of the respective welding machine or wire feed unit. The settings are defined by changeover switches or by setting special parameters (dependent on the control).

Infinite adjustment of the operating point (wire speed/welding voltage).

5.7 MMA welding

5.7.1 Welding task selection

Operating element	Action	Result
		Welding process selection Signal light MMA E-HAND on.
Operating element	Action	Result
		Welding process selection Signal light MMAG FUGENHOBELN on.

NOTE

Special electrode holders and carbon electrodes are required for air arc gouging.

5.7.2 Welding current setting

The welding current is normally set using the "Wire speed" rotary dial.

Operating element	Action	Result	Displays
		Welding current is set	Setpoint setting

5.7.3 Arcforce

Operating element	Action	Result	Display
		Select arcforcing welding parameter LED for the button is on.	<div>0</div>
		Arcforcing setting for electrode types: (Setting range -40 to 40) Negative values Rutile Values around zero Basic Positive values Cellulose	<div>40</div> <div>-40</div>

5.7.4 Hotstart

The hotstart device improves the ignition of the stick electrodes using an increased ignition current.

- a) = Hotstart time
b) = Hotstart current
I = Welding current
t = Time





Figure 5-14

5.7.5 Antistick



Anti-stick prevents the electrode from annealing.

If the electrode sticks in spite of the Arcforce device, the machine automatically switches over to the minimum current within about 1 second to prevent the electrode from overheating. Check the welding current setting and correct according to the welding task!

Figure 5-15

5.8 Interfaces

CAUTION



Damage due to the use of non-genuine parts!

The manufacturer's warranty becomes void if non-genuine parts are used!

- Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!
- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.



Damage due to incorrect connection!

Accessory components and the power source itself can be damaged by incorrect connection!

- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.
- Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.
- Accessory components are detected automatically after the power source is switched on.

6 Maintenance, care and disposal



DANGER



Risk of injury from electric shock!

Cleaning machines that are not disconnected from the mains can lead to serious injuries!

- Disconnect the machine completely from the mains.
- Remove the mains plug!
- Wait for 4 minutes until the capacitors have discharged!

6.1 General

When used in the specified environmental conditions and under normal operating conditions, this machine is largely maintenance-free and requires a minimum of care.

There are some points, which should be observed, to guarantee fault-free operation of your welding machine. Among these are regular cleaning and checking as described below, depending on the pollution level of the environment and the length of time the unit is in use.

6.2 Maintenance work, intervals

6.2.1 Daily maintenance tasks

- Mains supply lead and its strain relief
- Welding current cables (check that they are fitted correctly and secured)
- Gas tubes and their switching equipment (solenoid valve)
- Gas cylinder securing elements
- Operating, message, safety and adjustment devices (Functional test)
- Other, general condition

6.2.2 Monthly maintenance tasks

- Casing damage (front, rear and side walls)
- Transport rollers and their securing elements
- Transport elements (strap, lifting lugs, handle)
- Selector switches, command devices, emergency stop devices, voltage reducing devices, message and control lamps
- Check coolant tubes and their connections for impurities
- Check that the wire guide elements (inlet nipple, wire guide tube) are fitted securely.

6.2.3 Annual test (inspection and testing during operation)

NOTE



The welding machine may only be tested by competent, capable persons!

A capable person is one who, because of his training, knowledge and experience, is able to recognise the dangers that can occur while testing welding power sources as well as possible subsequent damage and who is able to implement the required safety procedures.



For further information, please see the accompanying supplementary sheets "Machine and Company Data, Maintenance and Testing, Warranty"!

A periodic test according to IEC 60974-4 "Periodic inspection and test" has to be carried out. In addition to the regulations on testing given here, the relevant local laws and regulations must also be observed.

6.3 Maintenance work



DANGER



Do not carry out any unauthorised repairs or modifications!

To avoid injury and equipment damage, the unit must only be repaired or modified by specialist, skilled persons!

The warranty becomes null and void in the event of unauthorised interference.

- Appoint only skilled persons for repair work (trained service personnel)!

Repair and maintenance work may only be performed by qualified authorised personnel; otherwise the right to claim under warranty is void. In all service matters, always consult the dealer who supplied the machine. Return deliveries of defective equipment subject to warranty may only be made through your dealer. When replacing parts, use only original spare parts. When ordering spare parts, please quote the machine type, serial number and item number of the machine, as well as the type designation and item number of the spare part.

6.4 Disposing of equipment

NOTE



Proper disposal!

The machine contains valuable raw materials, which should be recycled, and electronic components, which must be disposed of.

- Do not dispose of in household waste!
- Observe the local regulations regarding disposal!



6.4.1 Manufacturer's declaration to the end user

- According to European provisions (guideline 2002/96/EG of the European Parliament and the Council of January, 27th 2003), used electric and electronic equipment may no longer be placed in unsorted municipal waste. It must be collected separately. The symbol depicting a waste container on wheels indicates that the equipment must be collected separately.
This machine is to be placed for disposal or recycling in the waste separation systems provided for this purpose.
- According to German law (law governing the distribution, taking back and environmentally correct disposal of electric and electronic equipment (ElektroG) from 16.03.2005), used machines are to be placed in a collection system separate from unsorted municipal waste. The public waste management utilities (communities) have created collection points at which used equipment from private households can be disposed of free of charge.
- Information about giving back used equipment or about collections can be obtained from the respective municipal administration office.
- EWM participates in an approved waste disposal and recycling system and is registered in the Used Electrical Equipment Register (EAR) under number WEEE DE 57686922.
- In addition to this, returns are also possible throughout Europe via EWM sales partners.

6.5 Meeting the requirements of RoHS

We, EWM HIGHTEC Welding GmbH Mündersbach, hereby confirm that all products supplied by us which are affected by the RoHS Directive, meet the requirements of the RoHS (Directive 2002/95/EC).

7 Rectifying faults

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer.

7.1 Customer checklist

Legend

↘: Fault/Cause

✕: Remedy

NOTE



The correct machine equipment for the material and process gas in use is a fundamental requirement for perfect operation!

Wire feed problems

- ↘ Contact nozzle blocked
 - ✕ Clean, spray with separating agent and replace if necessary
- ↘ Setting the spool brake (see "Setting the spool brake" chapter)
 - ✕ Check settings and correct if necessary
- ↘ Setting pressure units (see "Inching wire electrodes" chapter)
 - ✕ Check settings and correct if necessary
- ↘ Worn wire rolls
 - ✕ Check and replace if necessary
- ↘ Wire feed motor without supply voltage (automatic cutout triggered by overloading)
 - ✕ Reset triggered fuse (rear of the power source) by pressing the key button
- ↘ Kinked hose packages
 - ✕ Extend and lay out the torch hose package
- ↘ Wire guide core or spiral is dirty or worn
 - ✕ Clean core or spiral; replace kinked or worn cores

Functional errors

- ↘ Machine control without displaying the signal lights after switching on
 - ✕ Phase failure > check mains connection (fuses)
- ↘ No welding performance
 - ✕ Phase failure > check mains connection (fuses)
- ↘ Various parameters cannot be set
 - ✕ Entry level is blocked, disable access lock (see chapter entitled "Lock welding parameters against unauthorised access")
- ↘ Connection problems
 - ✕ Make control lead connections and check that they are fitted correctly.
- ↘ Loose welding current connections
 - ✕ Tighten power connections on the torch and/or on the workpiece
 - ✕ Tighten contact tip/collet correctly

7.2 Error messages (power source)

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer.

NOTE



A welding machine error is indicated by an error code being displayed (see table) on the display on the machine control.

In the event of a machine error, the power unit is shut down.

- Document machine errors and inform service staff as necessary.
- If multiple errors occur, these are displayed in succession.

Error	Category		Possible cause	Remedy
	a)	b)		
Err 1	-	x	Mains overvoltage	Check the mains voltages and compare with the connection voltages of the welding machine (see Technical Data, chapter 1)
Err 2	-	x	Mains undervoltage	
Err 3	x	-	Welding machine, excess temperature	Allow the machine to cool down (mains switch to "1")
Err 4	-	x	Low coolant level	Top up the coolant Leak in the coolant circuit > rectify the leak and top up the coolant Coolant pump is not working > check excess current release on air cooling unit
Err 5	-	x	Error WF unit, WF motor fault, Speedometer error	Check wire feed unit check wire-feeding no signal from speedometer, > inform Service
Err 7	-	x	Secondary overvoltage	Inverter error > inform Service
Err 8	-	x	Earth fault between welding wire and earth line	Separate the connection between the welding wire and casing or an earthed object
Err 9	x	-	Fast shut-down triggered by BUSINT X10 or RINT X12	Rectify error on robot
Err 10	-	x	Arc interruption triggered by BUSINT X10 or RINT X12	Check wire feed
Err 11	-	x	Ignition fault after 5 s triggered by BUSINT X10 or RINT X12	Check wire feed

Category legend for error reset

- a) The error message will disappear once the error has been rectified.
- b) Errors can only be reset by switching the machine off and back on again.

8 Technical data

NOTE



Performance specifications and guarantee only in connection with original spare and replacement parts!

8.1 Taurus Basic S drive 4L WE

Supply voltage	42 VAC/60 VDC
Max. welding current at 60% DC	550 A
Wire feed speed	0.5 m/min to 24 m/min
Factory-fit roller equipment	1.0 + 1.2 mm (for steel wire)
Drive	4-roller (37 mm)
Connecting the welding torch	Welding torch central connection (Euro)
Protection classification	IP 23
Ambient temperature	-20 °C to +40 °C
Dimensions L x W x H in mm	690 x 300 x 410
Weight	15,1 kg
EMC class	A
Constructed to standards	IEC 60974-1, -5, -10 / C €

8.2 Taurus Basic S drive 4 WE

Supply voltage	42 VAC/60 VDC
Max. welding current at 60% DC	550 A
Wire feed speed	0.5 m/min to 24 m/min
Factory-fit roller equipment	1.0 + 1.2 mm (for steel wire)
Drive	4-roller (37 mm)
Connecting the welding torch	Welding torch central connection (Euro)
Protection classification	IP 23
Ambient temperature	-20 °C to +40 °C
Dimensions L x W x H in mm	680 x 460 x 265
Weight	24 kg
EMC class	A
Constructed to standards	IEC 60974-1, -5, -10 / C €

9 Accessories

NOTE



Performance-dependent accessories like torches, workpiece leads, electrode holders or intermediate hose packages are available from your authorised dealer.

9.1 General accessories

Type	Designation	Item no.
AK300	Adapter for K300 basket coil	094-001803-00001
HOSE BRIDGE	Tube bridge	092-007843-00000

9.2 Remote control / connection cable

Type	Designation	Item no.
R11 19POL	Remote control	090-008601-00502
RG11 19POL 5M	Remote control	090-008107-00000
RA5 19POL 5M	Remote control e.g. connection cable	092-001470-00005
RA10 19POL 10M	Remote control e.g. connection cable	092-001470-00010
RA20 19POL 20M	Remote control e.g. connection cable	092-001470-00020

9.3 Options

9.3.1 Taurus Basic S drive 4L WE

Type	Designation	Item no.
ON DK DRIVE 4L T/P	Retrofit option for Tetrix / Phoenix / Taurus drive 4L star handle	092-002112-00000
ON RMSDV2 4L/41L	Optional wheel assembly retrofit kit for drive 4L	090-008151-00000
ON CMF drive 4L	Optional retrofit crane suspension for drive 4L	092-002483-00000

9.3.2 Taurus Basic S drive 4 WE

Type	Designation	Item no.
ON RMSD 4/41	Optional wheel assembly retrofit kit drive 4/41	090-008035-00000
ON DK Phoenix drive 4	Pivot support for housing a drive 4 type wire feed unit	092-002280-00000

10 Replaceable parts

10.1 Wire feed rollers

CAUTION



Damage due to the use of non-genuine parts!

The manufacturer's warranty becomes void if non-genuine parts are used!

- Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!
- Only insert and lock accessory components into the relevant connection socket when the machine is switched off.

10.1.1 Wire feed rollers for steel wire

Type	Designation	Item no.
FE 2DR4R 0,6+0,8	Drive rollers, 37 mm, steel	092-000839-00000
FE 2DR4R 0,8+1,0	Drive rollers, 37 mm, steel	092-000840-00000
FE 2DR4R 0,9+1,2	Drive rollers, 37 mm, steel	092-000841-00000
FE 2DR4R 1,0+1,2	Drive rollers, 37 mm, steel	092-000842-00000
FE 2DR4R 1,2+1,6	Drive rollers, 37 mm, steel	092-000843-00000
FE/AL 2GR4R	Counterpressure rollers, smooth, 37mm	092-000844-00000

10.1.2 Wire feed rollers for aluminium wire

Type	Designation	Item no.
AL 4ZR4R 0,8+1,0	Twin rollers, 37 mm, for aluminium	092-000869-00000
AL 4ZR4R 1,0+1,2	Twin rollers, 37 mm, for aluminium	092-000848-00000
AL 4ZR4R 1,2+1,6	Twin rollers, 37 mm, for aluminium	092-000849-00000
AL 4ZR4R 2,4+3,2	Twin rollers, 37 mm, for aluminium	092-000870-00000

10.1.3 Wire feed rollers for cored wire

Type	Designation	Item no.
ROE 2DR4R 0,8/0,9+0,8/0,9	Drive rollers, 37 mm, cored wire	092-000834-00000
ROE 2DR4R 1,0/1,2+1,4/1,6	Drive rollers, 37 mm, cored wire	092-000835-00000
ROE 2DR4R 1,4/1,6+2,0/2,4	Drive rollers, 37 mm, cored wire	092-000836-00000
ROE 2DR4R 2,8+3,2	Drive rollers, 37 mm, cored wire	092-000837-00000
ROE 2GR4R	Counterpressure rollers, knurled, 37mm	092-000838-00000

10.1.4 Conversion sets

Type	Designation	Item no.
URUE VERZ>UNVERZ FE/AL 4R	Conversion kit, 37mm, 4-roller drive on non-toothed rollers (steel/aluminium)	092-000845-00000
URUE AL 4ZR4R 0,8+1,0	Conversion kit, 37mm, 4-roller drive for aluminium	092-000867-00000
URUE AL 4ZR4R 1,0+1,2	Conversion kit, 37mm, 4-roller drive for aluminium	092-000846-00000
URUE AL 4ZR4R 1,2+1,6	Conversion kit, 37mm, 4-roller drive for aluminium	092-000847-00000
URUE AL 4ZR4R 2,4+3,2	Conversion kit, 37mm, 4-roller drive for aluminium	092-000868-00000
URUE ROE 2DR4R 0,8/0,9+0,8/0,9	Conversion kit, 37mm, 4-roller drive for cored wire	092-000830-00000
URUE ROE 2DR4R 1,0/1,2+1,4/1,6	Conversion kit, 37mm, 4-roller drive for cored wire	092-000831-00000
URUE ROE 2DR4R 1,4/1,6+2,0/2,4	Conversion kit, 37mm, 4-roller drive for cored wire	092-000832-00000
URUE ROE 2DR4R 2,8+3,2	Conversion kit, 37mm, 4-roller drive for cored wire	092-000833-00000

<div> <div>D</div> Verschleißteile 4 Rollen-Antrieb Ø = 37mm </div> <div> St= Stahl Al= Aluminium CrNi= Edelstahl Cu= Kupfer </div>		<div> <div>GB</div> Wear parts 4-Roller drive system Ø = 37mm </div> <div> St= Steel Al= Aluminium CrNi= Stainless steel Cu= Copper </div>	
V-Nut: St-, CrNi-, Cu-Draht „Standard V-Nut“, oben unverzahnt und glatt, Rollenbezeichnung: „1,0“		V-groove: St-, CrNi-, Cu wire "Standard V-groove", on the top ungeared and plane, rolls description: "1,0"	
Antriebsrollen- Ø (b): Drive rolls- Ø (b): 0,6 + 0,8 0,8 + 1,0 0,9 + 1,2 1,0 + 1,2 1,2 + 1,6		Ersatzset: Spare set: 092-000839-00000 092-000840-00000 092-000841-00000 092-000842-00000 092-000843-00000	
Gegendruckrollenset (a) <i>Set of counter pressure rolls (a)</i> Umrüstung verzahnt → unverzahnt: <i>conversion geared → ungeared:</i>		092-000844-00000 092-000845-00000	
U-Nut: Al-, Cu-Draht „Option U-Nut“, oben verzahnt, Rollenbezeichnung: „1,0 A2“		U-groove: Al-, Cu wire "Option U-groove", on the top geared-twin rolls, rolls description: "1,0 A2"	
Antriebsrollen- Ø (a+b): Drive rolls- Ø (a+b): 0,8 + 1,0 1,0 + 1,2 1,2 + 1,6 2,4 + 3,2		Ersatzset: Spare set: 092-000869-00000 092-000848-00000 092-000849-00000 092-000870-00000	
Umrüstset: Conversion set: 092-000867-00000 092-000846-00000 092-000847-00000 092-000868-00000			
U-Nut gerändelt: Füll-/Röhrchendraht „Option U-Nut gerändelt“, oben verzahnt, ohne Nut gerändelt, Rollenbezeichnung: „1,0-1,2 R“		knurled U-groove: Cored wire "Option knurled U-groove", on the top geared, without knurled groove, rolls description: "1,0-1,2 R"	
Antriebsrollen- Ø (b): Drive rolls- Ø (b): 0,8 / 0,9 + 0,8 / 0,9 1,0 / 1,2 + 1,4 / 1,6 1,4 / 1,6 + 2,0 / 2,4 2,8 + 3,2		Ersatzset: Spare set: 092-000834-00000 092-000835-00000 092-000836-00000 092-000837-00000	
Umrüstset: Conversion set: 092-000830-00000 092-000831-00000 092-000832-00000 092-000833-00000			
Gegendruckrollenset (a): <i>Set of counterpressure rolls (a):</i>		092-000838-00000	

Figure 10-1

11 Appendix A

11.1 Overview of EWM branches

Headquarters

EWM HIGHTEC WELDING GmbH

Dr. Günter-Henle-Straße 8
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -244
www.ewm-group.com · info@ewm-group.com

Technology centre

EWM HIGHTEC WELDING GmbH

Forststr. 7-13
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -144
www.ewm-group.com · info@ewm-group.com

Production, Sales and Service

EWM HIGHTEC WELDING GmbH

Dr. Günter-Henle-Straße 8
56271 Mündersbach · Germany
Tel: +49 2680 181-0 · Fax: -244
www.ewm-group.com · info@ewm-group.com

EWM HIGHTEC WELDING (Kunshan) Ltd.

10 Yuanshan Road, Kunshan · New & High-tech Industry Development Zone
Kunshan · Jiangsu · 215300 · People's Republic of China
Tel: +86 512 57867-188 · Fax: -182
www.ewm-group.com/cn · info.cn@ewm-group.com

EWM HIGHTEC WELDING AUTOMATION GmbH

Boxbachweg 4
08606 Oelsnitz/V. · Germany
Tel: +49 37421 20-300 · Fax: -318
www.ewm-group.com/automation · automation@ewm-group.com

EWM HIGHTEC WELDING s.r.o.

Tr. 9. května 718 / 31
407 53 Jiřikov · Czech Republic
Tel: +420 412 358-551 · Fax: -504
www.ewm-group.com/cz · info.cz@ewm-group.com

Sales and Service Germany

EWM HIGHTEC WELDING GmbH

Lindenstraße 1a
38723 Seesen-Rhüden · Tel: +49 5384 90798-0 · Fax: -20
www.ewm-group.com/handel · nl-seesen@ewm-group.com

EWM Schweißtechnik-Handels-GmbH

Sachsstraße 28
50259 Pulheim · Tel: +49 2234 697-047 · Fax: -048
www.ewm-group.com/handel · nl-koeln@ewm-group.com

EWM Schweißtechnik-Handels-GmbH

In der Florinskaul 14-16
56218 Mülheim-Kärlich · Tel: +49 261 988898-0 · Fax: -20
www.ewm-group.com/handel · nl-muelheim@ewm-group.com

EWM Schweißtechnik-Handels-GmbH

Eiserfelder Straße 300
57080 Siegen · Tel: +49 271 3878103-0 · Fax: -9
www.ewm-group.com/handel · nl-siegen@ewm-group.com

EWM HIGHTEC WELDING GmbH

Vertriebs- und Technologiezentrum
Draisstraße 2a
69469 Weinheim · Tel: +49 6201 84557-0 · Fax: -20
www.ewm-group.com/handel · nl-weinheim@ewm-group.com

EWM Schweißtechnik Handels GmbH

Rittergasse 1
89143 Blaubeuren · Tel: +49 7344 9191-75 · Fax: -77
www.ewm-group.com/handel · nl-ulm@ewm-group.com

EWM Schweißtechnik Handels GmbH

Heinkelstraße 8
89231 Neu-Ulm · Tel: +49 731 7047939-0 · Fax: -15
www.ewm-group.com/handel · nl-ulm@ewm-group.com

EWM HIGHTEC WELDING AUTOMATION GmbH

Steinfeldstrasse 15
90425 Nürnberg · Tel: +49 911 3841-727 · Fax: -728
www.ewm-group.com/automation
automation-nl-nuernberg@ewm-group.com

Sales and Service International

EWM HIGHTEC WELDING GmbH

Fichtenweg 1
4810 Gmunden · Austria · Tel: +43 7612 778 02-0 · Fax: -20
www.ewm-group.com/at · info.at@ewm-group.com

EWM HIGHTEC WELDING UK Ltd.

Unit 2B Coopies Way · Coopies Lane Industrial Estate
Morpeth · Northumberland · NE61 6JN · Great Britain
Tel: +44 1670 505875 · Fax: -514305
www.ewm-group.com/uk · info.uk@ewm-group.com

EWM HIGHTEC WELDING (Kunshan) Ltd.

10 Yuanshan Road, Kunshan · New & High-tech Industry Development Zone
Kunshan · Jiangsu · 215300 · People's Republic of China
Tel: +86 512 57867-188 · Fax: -182
www.ewm-group.com/cn · info.cn@ewm-group.com

EWM HIGHTEC WELDING Sales s.r.o. / Prodejní a poradenské centrum

Tyršova 2106
256 01 Benešov u Prahy · Czech Republic
Tel: +420 317 729-517 · Fax: -712
www.ewm-group.com/cz · sales.cz@ewm-group.com

EWM HIGHTEC WELDING FZCO / Regional Office Middle East

LOB 21 G 16 · P.O. Box 262851
Jebel Ali Free Zone · Dubai, UAE · United Arab Emirates
Tel: +971 48870-322 · Fax: -323
www.ewm-group.com/me · info.me@ewm-group.com